

Command Code List

Model:W54F5MP-WP

Preset position:Support 1-64(Excluded 8)

Patrol Routine:Support 8 Group(No.11-18)

(1-7/9-16/17-24/25-32/33-40/42-48/49-56/57-64)

Command Code	Call	Preset
65	<p align="center">Call Patrol Routine (Group 1,Between Preset 1 to 7) 5 Seconds Stay at Each Preset Position</p> <p>* If there is no manually operation for 120 Seconds, it will resume Watch position function.</p>	<p>Setup Watch position Mode 1: Setup Preset Position as Watch position(Preset 65,then Preset any number from 1-7) Mode 2: Setup Patrol Routine as Watch position(Preset 65,then Preset any number from 11-18)</p>
66	<p align="center">Call Patrol Routine (Group 2,Between Preset 9 to 16) 10 Seconds Stay at Each Preset Position</p>	Turn off Watch position Function
67	<p align="center">Call Patrol Routine (Group 3,Between Preset 17 to 24) 15 Seconds Stay at Each Preset Position</p>	
68	<p align="center">Call Patrol Routine (Group 4,Between Preset 25 to 32) 20 Seconds Stay at Each Preset Position</p>	<p>Power on Actions Setup Action 1: Setup Preset Position as Watch position(Preset 68,then Preset any number from 1-7) Action 2: Setup Patrol Routine as Watch position(Preset 65,then Preset any number from 11-18)</p>
70		Start Scanning Left&Right Edge when power on
72		No Actions When power on
87	Start Scanning Left&Right Edge at Low Speed (12 Seconds)	
88	Start Scanning Left&Right Edge at Middle Speed(8 Seconds)	
89	Start Scanning Left&Right Edge at High Speed(6.5 Seconds)	
90	Delete Preset Position	
92		Go to Left Edge
93		Go to Right Edge
94	Default Setting	
148	Turn on Smart Speed Control(Default On)	Turn off Smart Speed Control
152	<p align="center">Turn on Human Tracking(Default On)</p> <p>*If you manually control the rotation, it will automatically stop tracking. If there is no operation for 20 Second, it will resume automatic tracking.</p>	Turn off Human Tracking