

Network IP camera configuration

1

Address
http:// : Camera IP Address

4 Find/inspect...

User admin Password ***** Show Blank address to search for cameras

3 Make Generic

default username: admin
Password: admin

Media/video/RTSP port 554

2 Discovery/ONVIF port 8080

Video
Path /11
Params
Camera 1

Network options
Receive buffer (MB) 6.0
 Use RTP/UDP ports: 7000
 Send RTSP keep-alives
 Use RTSP/stream timecode
 Skip initial HTTP DNS and reachability tests
 Decoder compatibility mode
 Get events with PullPointSubscription

Audio
Path
Format 64 kbps G.711 u-law
 Setup RTSP back-channel for talk support (PCM-U format)

5 OK Cancel Help