


How to change my Camera Password via phone APP

1 . Please make sure you connect this camera successfully.



2 . Click "Change Password"



Camera

DDDD-159233-URWEY

Change Password >

Alarm Setting >

Action with Alarm >

Recording Schedule >

Audio Setting >

Video Setting >

Wi-Fi Setting >



3. Input the old password and new new password.

The image shows a mobile application interface for changing a password. At the top, there is a blue header with a back arrow and the text 'Change Password'. Below the header are three input fields, each with a red box around it and an arrow pointing to an explanatory text box:

- Old Password:** The input field contains five dots. The annotation box says 'Default password : admin'.
- New Password:** The input field contains seven dots. The annotation box says 'The password you want to change (max: 31 characters)'.
- Confirm Password:** The input field contains seven dots. The annotation box says 'Repeat the password'.

Below the input fields is a toggle switch labeled 'Show password' with an unchecked radio button. At the bottom of the form is a blue button labeled 'Apply', which has an arrow pointing to an annotation box that says 'Click "Apply " to save the setting'. The bottom portion of the screen is a light gray area, likely representing the rest of the application interface.

Note: Please remember to add the camera again after you change the password.