


How to add WIFI camera to Ispy

1, RTSP to add

1、 main stream: rtsp://ip address/11

2、 vice stream: rtsp://ip address/12

Find “FFMPEG (H264)” this column, fill in information of RTSP in the URL.After adding can test test is successful



Go to “Camera” option

Input your camera ip address, User name and Password, click “Finish”, add camera succeed.

Edit Camera (ID: 1, DIR: UJFQZ)

Camera Motion Detection Alerts Recording PTZ Images FTP Cloud Storage Scheduling Storage

Video Source

Source Adv. Properties Inputs Options

Name

Groups [Help](#)

Camera Active Fill

Transform

Timestamp

Mask Image

Picture In Picture

Maximum Framerate When Recording

Microphone

Microphone None [Help](#)

Ignore Audio

Talk

Camera Model [Settings](#)

IP Address	<input type="text" value="192.168.20.59"/>	Port	<input type="text" value="80"/>
Username	<input type="text" value="admin"/>	Password	<input type="text" value="*****"/>

Exit this to enable alerts and recording [Copy To](#) [Help](#)