


---

## How to setting the camera's time and zone

**First**, please make sure you connect the camera successfully. If have any problem in its connection, please contact US [support@boavision.com](mailto:support@boavision.com)

1. "Setting"- "Time Setting"- "Sync with Phone Time"



< Back Time Setting

Device Time 2017-12-05 23:50:37

Sync with Phone Time



Device Time Zone GMT+8 >

Phone Time Zone GMT+8

Saving Time Zone For Device

2. Set the camera's time zone.

< Back Time Setting

Device Time 2017-12-05 23:50:37

Sync with Phone Time

Device Time Zone GMT+8 >



Phone Time Zone GMT+8

Saving Time Zone For Device

< Back Zones Done



GMT-2

Azores;Cape Verde;

GMT-1

London;Iceland;Lisbon;

GMT 0



Paris;Rome;Berlin;Madrid;

GMT+1

Israel;Athens;Cairo;Jerusalem;

GMT+2

Moscow;Nairobi;Riyadh;

GMT+3

Baku;Tbilisi;Abu Dhabi;Mascot;


GMT+4

New Delhi;Islamabad;

GMT+5



Choose the right time zone.



**Note:**

Please don't turn on the "Daylight Saving Time" in standard time.

6. Save the time setting.

