



Boavision Technology Co., LTD

E-Mail: Support@Boavision.com *(Reply within 24hours!)*


Phone: +1484-862-1346 *(9AM-6PM EST Mon-Fri)*

Add: 7050 Frankford Ave Ste 1 Philadelphia, Pa 19135

Very Importance Tips:

The PC Client default user name is admin, password is empty

Please do not input your camera password here.



Client Software For Windows

<https://bit.ly/3hy5Ist>

Client Software For Mac

<https://bit.ly/3v1Y1i7>

Download The "Camhipro" App From The Apple App Store Or From The Google Play Store.

Live View Client Software Download



BOAVISION®

YouTube

Scan QR Code
Visit Quick Start Video

boavision official

View YouTube Support Video

Boavision Support | Initial Setup for HD22M102M Security Camera outdoor

<https://youtu.be/5FyiO63vfCc>

Boavision Support | Open Intelligent Auto Tracking

<https://youtu.be/Pzup0yb7Xag>

Boavision Support | Setup Motion Detection Recording and Mail Push Alert

<https://youtu.be/xB5hvgSjbXo>

Boavision Support | How To Playback and Download Videos From Micro SD Card

<https://youtu.be/vVKfMFh2YGY>

Boavision Support | HiP2P Windows Client User Guide

<https://youtu.be/T8gVt2OL7oA>

Boavision Support | How to Switch Three modes of night vision, Ordinary/Color/Intelligent

<https://youtu.be/yxUFvsAzmmU>

Boavision Support | 3rd Party Software Connect Configuration

<https://youtu.be/1vqUHHFoHeM>

Technical Support Team:

Before You Return The Product, Please Contact Our After-Sales Team To Confirm Whether The Product Is Faulty.

E-Mail: Support@Boavision.com **(Reply within 24hours!)**

Phone: +1484-862-1346 **(9AM-6PM EST Mon-Fri)**

Camera Works On Other Devices

ONVIF: If you want to add the camera to 3rd party onvif software/device, please find the camera ip address from device information (setting page), usually we should use.

information below: Protocol: ONVIF , Ip address , Onvif port : 8080 , User: admin , Password: admin (for some special software may need more information, please contact us for remote online help, we use Teamviewer to help you to setup remotely).

RTSP:

The camera RTSP port is 554, and there are two live H.264 rtsp stream,

main stream: http://ip address:554/11

sub steam: http://ip address:554/12

E.g. If camera ip address is 192.168.1.123, main steam: http://192.168.1.123:554/11

Boavision Support | 3rd Party Software Connect Configuration

<https://youtu.be/1vqUHHFoHeM>