

Quick Start Manual

Hardware Quick Start:

- 1) Mount Camera.
- 2) Plug Ethernet cable into camera
- 3) Plug power cable into camera and turn on.

Software Quick Start:

- 1) Download "HiSee" APP from your app store on your android or iPhone. (QR code at end of instructions for direct link)
- 2) Open APP and tap "Add Device"
- 3) Choose "Wired Device"
- 4) Press "Lan GID Search."
- 5) Select the Camera from the list of found devices.

Onvif NVR Setup

- a. Go to Settings -> Enter Password and unlock -> Channel -> IP Camera Tab
- b. It will automatically search for IP Cameras on the network.
- c. Select correct camera.
- d. Enter Camera's login details (default user is "admin", password is chosen on camera setup as above.)

More operations about setting this camera up with Onvif NVRs, Please refer to user manual for your device.

HiSee App QR Code

Apple



Android



Please refer to the user manual for more operations, if you have any further questions or concerns, please contact us at Support@boavision.com.